

# EROSE WHIRLING PATTERN HYDROMETER



Glass Agencies are  
manufacturer of **Whirling  
Pattern Hydrometer**  
EROSE Brand.

## ❖ Specification :

- Material : Glass & Plastic
- Color : Transparent
- Length : 7 Inches
- Manufacturer Name : Glass Agencies
- Brand : EROSE
- Range : 50 degree

## ❖ Features:

- \* Whirling hygrometer has a wet-bulb thermometer and a dry-bulb thermometer mounted on a handle.
- \* The wet-bulb thermometer is covered with a moistened wick, while the dry-bulb thermometer remains dry.
- \* The instrument is whirled rapidly for 30 seconds, and then the temperature readings from both thermometers are taken.
- \* The relative humidity is determined by comparing the readings with a hygrometric table.

## GLASS AGENCIES

5309, Anaj Mandi, Ambala Cantt. 133001 (Haryana) INDIA

Office : +91 89304-07858

Mobile : +91 98968-07858

E-mail : [glassagencies@gmail.com](mailto:glassagencies@gmail.com)

Website : [www.glassagencies.com](http://www.glassagencies.com)

